

RFA Loopback Setup for 3.0T with Dual-Drive RF Amplifier – headdummy (Bird RF power measurement kits)

Landmark:

On center of head coil.

*For DPP systems: Set attenuation to 20 dB.

Connect the system cable to re-route box J7 or RFSBv1 B1 (normally connected to combiner J11, below).

For DPP systems: Connect the system cable to Rx Dist J13 (normally connected to combiner J11, below).

