



To A1 Power Disconnect  
5169224  
120VAC  
2397751  
120VAC  
2391751-3

RUN # 101 Scan INTL (Interlock)

RUN # 100 Control

RUN # 054 120 VAC (bundle)

RUN # 052 120/208Y Power

Table

OpenOC with Z8G4

RUN # 056 #2 Ground

RUN # 051 HVAC Axial Mir Power

RUN # 103 LAN (RJ45)

RUN # 050 HVDC Power

RUN # 053 Console Power

RUN # 055 1/0 Ground

RUN # 102 LAN (RJ45)

RUN # 053 IFC and PANEL

RUN # 104 Table IF

RUN # 052 120/208Y Power

RUN # 103 LAN (RJ45)

RUN # 051 HVAC Axial Mir Power

RUN # 102 LAN (RJ45)

RUN # 050 HVDC Power

RUN # 101 Scan INTL (Interlock)

RUN # 055 1/0 Ground